



INSTALLATION MANUAL & USER GUIDE

Please read carefully before installing and use

BG100-BDC BoomController

36V DC Brushless Barrier Control Box



WARNING

 AUTOMATIC BARRIERS ARE NOT FOR PEDESTRIAN!


To reduce the risk of INJURY or DEATH, read and follow all instructions

- NEVER let children operate or play with barrier control .controller MUST be installer at least 1.5m above the ground.
- PEDESTRIANS SHOULD NOT CROSS THE PATH OF THE MOVING BARRIER.
- Automatic boom barrier is designed for vehicles ONLY. Pedestrians MUST use separate entrance.
- Installation and maintenance MUST be executed by qualified service person. Keep boom barriers properly maintained.
- Ground wire and current breaker MUST be connected.
- Power MUST be cut off when performing installation or maintenance.
- When power outage, power MUST be cut off before using the manual release under the motor to open the barrier.
- ONLY operate when the boom barrier is in sight.
- NEVER perform operating or setting without the boom installed. This WILL result in severe injury.
- NEVER dismount the boom when barrier is at close status with spring attached. This WILL result in sever injury, even death.
- DO NOT replace the original wire.


● **SAVE THESE INSTRUCTIONS.**

1、 Controller

1. Electrical connections



2. Limits Setting



Attention: Limits are set well in factory any change made on length, or maintain and change controller. please follow steps below. Before power on, manually adjust boom to middle position 45° .

2. Transmitter (Remote control) setting

2.1 Transmitter's code setting

Press "LEARN BUTTON", the "LEARN LED" light on, then, press and hold the button which you choose on the transmitter till the "LEARN LED" flashes and goes out, now, the transmitter is code. Other transmitter can be coded as this way.

2.2 Erasing the transmitter's code

Press "LEARN BUTTON" and hold on to make the "LEARN LED" light on and till go out. Now, all codes of transmitters which had been learnt are cleared.

3. Error Codes

1. Error Codes

Code	Meaning	Solution
<i>ER00</i>	Over voltage	Check the voltage of input power
<i>ER01</i>	Under voltage	
<i>ER02</i>	Over current	Check the current
<i>ER03</i>	Running overtime	Check the mechanical system
<i>ER04</i>	Encoder communication is abnormal	Check the encoder wires and connection
<i>ER05</i>	Hall sensor is abnormal	Check hall terminal and wires connection
<i>ER06</i>	Motor locked Rotor	Check the Mechanical system Check the motor wires connectors
<i>ER07</i>	Air wave sensor is triggered	Remove the object that block the air wave
<i>ER08</i>	Loop detector is triggered	Remove the object that block the Loop detector
<i>ER09</i>	Photocell is triggered	Remove the object that block the photo beam
<i>ER10</i>	Limit is invalid	Reset "P--1" & "P--2"
<i>ER11</i>	Abnormal position of boom	Press button or manually adjust boom to normal position

2. Trouble Shooting

Trouble	Possible Reason	Solution
power on , no display	No input power	Check power supply
	Power cable connection is incorrect	Check the terminals and connect correctly
	Fuse blowout	Change a new fuse
Display Error code	Refer to Error Codes List	Refer to Error Codes List
Operate transmitter but no neaution	No battery	Change batteries
	Weak signal	Avoid obstacle or Interference source
	The remote control is flooded or damaged	Change a new transmitter
Motor doesn't work	Motor wire broken or damaged	Check the wire connection or change motor
The boom runs in the opposite direction of the button command	Motor running direction is incorrectly	Adjust the parameter F-06 to set the running direction of motor

1) Boom doesn't reach correct position when opening and closing

Possible Reason:

1. Incorrect Linkage adjustment
2. Incorrect Limits setting




Solution:


1. Open the chassis door and cover. A. when the active connecting rod and the middle connecting rod coincide, whether the brake rod is in the opening position; B. when the active connecting rod is in line with the middle connecting rod, whether the brake rod is in the closing position; If the above state can't be achieved by adjust the screw sleeve adjustment, so that the two connecting rods coincide when the brake rod is in the vertical(open) position, two brake rod into a straight line when the brake rod is in the level(close) position.

2. Reset the limit position through the controller


Open Position



Close Position



2) Boom shakes at open limit and close limit:




4. Appendix

1. Function Parameters


Function code	Meaning	Description
<i>F-00</i>	Boom type option	Refer to Appendix 3
<i>F-01</i>	Open speed grade	Ranges from 1 to 10, with higher numbers faster
<i>F-02</i>	Open speed grade	Ranges from 1 to 10, with higher numbers faster
<i>F-03</i>	Auto-close timer (s)	Default is 0 means auto close, function is invalid Increase the value, the value means the auto close time
<i>F-04</i>	Open resistance sensitivity	Default: 40 The smaller, the more sensitive
<i>F-05</i>	Close resistance sensitivity	Default: 30 The smaller, the more sensitive
<i>F-06</i>	Motor's running direction	0: Turing (default) 1: Reverse
<i>F-07</i>	Protection signal input mode	0: N.O. (default) 1: N.C.
<i>F-08</i>	Light mode	0: Red and green light (default) 1: Alarm
<i>F-09</i>	Test mode	0: Disable (default) 1: Valid
<i>F-10</i>	Factory setting	10: Caution! refer to Appendix 5
<i>F-11</i>	Transmitter type option	0: Transmitter control is invalid 26: T26 Transmitter 23: T23 Transmitter (default) 28: T28 Transmitter
<i>F-12</i>	Auto open when power on	0: Disable (default) 1: Valid
<i>F-13</i>	Auto close when power off	0: Disable (default) 1: Valid
<i>F-14</i>	Shielded angle	0~100%
<i>F-15</i>	Loop detector count mode	0: Disable (default) 1: Valid
<i>F-16</i>	Stay open mode	0: Disable (default) 1: Valid

Function code	Meaning	Description
<i>P-01</i>	Open limit	The value of position when boom is vertical
<i>P-02</i>	Close limit	The value of position when boom is horizontal
<i>P-03</i>	Erase limit setting	0: no action (default) 1: Erase limit setting

Appendix2: Funtion Parameter Setting




Appendix3: Boom Type Option




Boom Type code	Meaning
0	Octagonal straight boom
1	Single fence boom
2	Foam round boom
3	Single rubber straight boom
4	Articular boom

Appendix4:Change the motor's running direction



Appendix5: Reset factory setting



Appendix6: Erasing the limit switch Setting

